

Update firmware devices 18x5 >= v1.4.2

Performing the firmware update:

The file "firmware.bin" must be copied in the root directory of a USB stick.
(supported is FAT32, extFAT for storage >=64GB is not supported yet).

1. Turn on the device.
2. Plug the USB stick into the USB interface of the device.
3. Open "Menu" → "Info".
4. Press button "Firmware update".
5. Enter "usb://firmware.bin" in the edit line and confirm with "OK".
6. A message appears that the firmware was successfully copied. Confirm the message "restart device" with "Yes".
7. The USB stick is no longer necessary now and can be removed.
8. When the update is finished a message appears on the screen.
9. Enter "Menu" → "Info" again.
10. Press button "MS1805 update".
11. A dialog with status bars appears.
12. Please wait until all the bars reach 100% and status OK.
13. Close the dialog with "OK".
14. The update is finished.